

# TECH UPDATE

## REQUIRED OVERHANG EXTERIOR DOORS

For best performance and to meet the standard warranty, any exterior door should be installed under a overhang or with sufficient protection. Adequate overhang depends on typical weather conditions of the area where the door is installed, but at the minimum means an overhang projecting a distance from the structure equal to one half the distance between the bottom of the door and the bottom of the overhang.

